

# Uniden®

## Model CE7203



### USER'S GUIDE GUÍA DE USUARIO


Please read this user's guide before using your phone  
Favor de leer este manual antes de utilizar su telefono

Distributor: US Telecom Ltd  
info@ustel.com.hk  
www.ustel.com.hk

### ENGLISH

#### PARTS CHECKLIST

Your package should contain the following items:



#### INSTALLATION AND SETUP

##### DESKTOP INSTALLATION (Fig.1 & Fig.2)




Fig.1




Fig.2

1. Adjust the **RINGER** volume switch to the desired setting. Default setting is **HI** (High).
2. Set the Flash time switch (600ms, 300ms, 100ms) to the appropriate setting. Default setting is **600ms**.
3. Slide the **PULSE/TONE** switch (back of the base) to **TONE** if you use Touch-Tone Service; set it to **PULSE** if you have rotary service.
4. Plug the handset cord into the handset, and into the telephone jack on the left side of the unit.
5. Plug the telephone line cord into a modular jack (RJ11C) and into the **LINE** jack on the back of the unit.
6. Place the handset to base cradle.

#### WALL MOUNT INSTALLATION

The telephone can be mounted on a wall phone plate (not included).

1. Adjust the wall mount knob on cradle of base of apply to wall mount.
2. Place the base to the wall mount plate.

#### USING FEATURES

##### MAKING A CALL

1. Lift the handset and wait for a dial tone.
2. Dial the telephone number using the keypad.

##### RECEIVING A CALL

Lift the handset to answer the call.

##### RINGER VOLUME CONTROL

Use the **RINGER** volume switch on the right side of the base to adjust the volume of the ringer.

##### FLASH BUTTON

Press the **FLASH** button instead of using the hook switch to activate customer calling services such as call waiting or call transfer, which are provided by your local phone company.

##### REDIAL BUTTON

Redial the last number you called by pressing the **REDIAL** button after you get a dial tone. Maximum digits of redial is 32.



Redial button Flash button

#### CARE AND MAINTENANCE

To keep your phone working and looking good, please follow these guidelines:

- Avoid putting near heating appliances and devices that generate electrical noise (for example, motors and fluorescent lamps).
- DO NOT expose to direct sunlight or moisture.
- Avoid dropping and other rough treatment of the unit.
- Never use a strong cleaning agent or abrasive powder because this will damage the finish.
- Retain the original package in case you need to return is at a later date.




Used equipment must be disposed of in compliance with current environmental protection regulations. You should dispose of it in an approved recycling centre.

### ESPAÑOL

#### LISTA DE PARTES

Asegúrese de que su embalaje contenga los siguientes artículos:



#### INSTALACIÓN Y CONFIGURACIÓN

##### INSTALACIÓN EN ESCRITORIO (Fig.1 & Fig.2)




Fig.1




Fig.2

1. Ajuste el interruptor de volumen del timbre (**RINGER**) en el nivel deseado. La configuración predeterminada es **HI** (alto).
2. Coloque el interruptor de tiempo de **FLASH** en la configuración adecuada (600ms, 300ms, 100ms). La configuración predeterminada es 600ms.
3. Deslice el botón de **TONO/PULSO** en la parte baja de la base para cambiar a **TONO** si está usando el servicio de Tono en un toque; fíjelo en **PULSO** si usted tiene un servicio rotativo.

4. Enchufe el cable espiral del auricular en el auricular y en la toma del teléfono que se encuentra en el lado izquierdo de la unidad.
5. Enchufe el cable de línea telefónica en la toma telefónica (RJ11C) y en la ranura de línea (LINE) que se encuentra en la parte posterior de la unidad.
6. Coloque el auricular en la base.

INSTALACIÓN EN PARED

El teléfono se puede colocar sobre una placa para pared (no incluida).

- 1. Ajuste la perilla para instalación en pared que se encuentra en la base para colocar el soporte para pared.
- 2. Coloque la base en la placa para pared.

UTILIZAR LAS FUNCIONES

REALIZAR UNA LLAMADA

- 1. Tome el auricular y espere el tono de marcado.
- 2. Marque el número de teléfono utilizando el teclado numérico.

RECIBIR UNA LLAMADA

Tome el auricular para contesta la llamada.

CONTROL DE VOLUMEN DEL TIMBRE


Utilice el interruptor de volumen del timbre (RINGER) que se encuentra en la parte lado derecho de la base para ajustar el volumen del timbre.

BOTÓN FLASH

Pulse el botón FLASH en lugar de utilizar el interruptor para activar los servicios de llamadas del cliente tales como llamada en espera o transferencia de llamadas, que son provistos por su empresa de telefonía local.

BOTÓN REDIAL

Vuelva a marcar el último número al que llamó pulsando el botón REDIAL despues de obtener tono de marcado. El número máximo de dígitos para rellamada es 32.



CUIDADO Y MANTENIMIENTO

Para mantener su teléfono en funcionamiento y en buen estado, siga las siguientes pautas:

- Evite colocar el teléfono cerca de aparatos de calor y dispositivos que generen ruido eléctrico (por ejemplo, motores o lámparas fluorescentes).
- NO exponga el teléfono a luz solar directa o humedad.
- Evite arrojar el teléfono o cualquier otro tratamiento brusco.
- NO utilice un agente de limpieza fuerte o polvo abrasivo ya que podría dañar el acabado.
- Conserve el empaque original en caso de que necesite devolver la unidad más adelante.



El equipo usado deberá eliminarse en cumplimiento de las regulmentaciones de protección del medio ambiente actuales. Deberá llevarlo a un centro de reciclado aprobado.

PRODUCTS - WARRANTY CARD  
產品保養證

CUSTOMER'S COPY 用戶存根/不需寄回

★ 保養條款 ★

1. 此保養證有效期為購買當日起計12個月。
2. 此保養證只適用於原本購買產品之顧客及不可轉讓。
3. 保養服務只限於保養期內，請出示保養證，發票正本及全套產品一併交回。客戶須負責將產品送往本公司之費用。
4. 零件及配件（火牛、電源線及電芯）之保養期為購買後90天，包括對電池的蓄電能量低於額定功率的80%以下及電池洩漏這兩種情況。
5. 保養證將不包括由下列情況所導致的損壞：(a) 產品曾經改變、修改及非由本公司修理過；(b) 正常磨損；(c) 不當裝配、使用、誤用、意外或疏忽；(d) 接觸水、雨、沙、塵埃、汗水、太過潮濕或接近熱源；(e) 使用其他品牌的配件。
6. 此保養證只在香港有效。
7. 由通知之日期起2個月內沒有領回已維修機件，公司有權自行處理有關機件，逾期失機，恕不負責。
8. 本公司有權隨時修訂保養條款，而無須先行通知客戶。

★ Warranty Conditions ★

1. This warranty commences on the date of original purchase and expires 12 months from that date.
2. This warranty extends only to the first consumer purchaser and is not transferable.
3. Warranty service will only be provided within the warranty period. To obtain service, the complete set of product shall be brought to our service centre at the purchaser's own expense, together with this warranty card and the original purchase invoice.
4. The warranty period for accessories (battery, adaptor, line cord) is 90 days commencing from the date of original purchase. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered.
5. The warranty does not cover defects or damage result from (a) modification, alteration or repair by persons other than the authorized personnel of the company; (b) normal wear and tear; (c) improper installation and operation, misuse, accident, negligence; (d) contact with water, rain, sand, dirt, extreme humidity or heat, heavy perspiration; (e) the use of other brand accessories.
6. The warranty is valid in Hong Kong only.
7. Any repaired items not collected by customers within 2 months from the date of notice will be disposed of at the discretion of the company.
8. The warranty conditions are subject to change by the company without giving prior notice to customer.

18.COM Electronics Pte Ltd.

WARRANTY CARD

CUSTOMER'S COPY : DO NOT MAIL THIS

Name: \_\_\_\_\_

Contact No. Tel: \_\_\_\_\_

Model: \_\_\_\_\_

Date Of Purchase: \_\_\_\_\_

Serial No.: \_\_\_\_\_

Dealer's Stamp: \_\_\_\_\_

Service Centre:  
Monday- Friday Opening Hours  
9:30am - 12:30pm, 2:00pm - 5:00pm  
Tel: 6278 8274

1. This warranty starts on the date of purchase and expires in 1 year. Customer must bring along this warranty card and original invoice or receipt together with the complete product for any repair services.
2. Any warranty application with no invoice and/or warranty card are regarded as invalid warranty. Customer must pay for repair charges.
3. This warranty is invalid if the product has been modified, altered and / or repaired by persons other than technician of our company or mishandled by customer.
4. This warranty is applicable to Singapore only.
5. This warranty does not cover damages caused by natural disasters such as flooding and lightning etc.
6. Customers are requested to collect repaired unit within two months from date of submission. Units not collected after 6 months will be disposed off by the company.

18.COM Electronics Pte Ltd, 159 Sin Ming Road, Amtech Building,  
#04-01, Singapore 575625